



It is important to saw a hole for the 628128 and solder it with bottom up!