

# Mini Status. 1.0.0.

Mini Status.

Version: 1.0.0

Update: 06/05/2001.

Author: Augusto Correa M. (HPMOYACK)

E-mail: moya@hotmail.com

Platform: Hp48

```
Sugestions: moya@hotmail.com
Work Memory: 20837 Bytes free. 37%
Version HP48-R
Copyright HP 1993
Fecha: 05/06/01
Hora: 09:21:42P
0 Libraries installed.
I/O settings
Mode Wire
NO overwrite
```

## Welcome to Mini Status Manual.

Here you can see how to use this program in your HP48.

### Installation.

There are two ways for installing this program, the first one is selecting from the ZIP file the library most appropriate for your HP48. The second one is loading the file “Mini Status INSTALLER” on your calculator and evaluating it. You can see the next screen:

```
MINI STATUS INSTALL
HP48: GX/G+ PORT: 0
IS JAVA INSTALLED?  ✓
SELECT YOUR HP48.
[CHOOSE] [CANCEL] [OK]
```

Here you can select your HP48 reference, the port where you want to install it and the JAVA verification support. The install program search JAVA library and it will be checked if the library is attached to home, otherwise it won't be checked. If you want to install Mini Status with JAVA support and you don't have JAVA installed, you could do it but Mini Status won't work until you install JAVA.

When you have finished selecting the appropriate library mode, you can select “OK” or press “ENTER”. Automatically the program install the library in the port indicated and your calculator will be restarted.

### JAVA users.

If you are a JAVA user, you can activate the possibility to loading at warmstart. It can be done with the command “STARTUP?”.

Automatically it shows this screen. When you select “Yes” the program creates a variable called ‘AUTOEXEC’ and is stored in the HOME directory.

```
Mini Status at startup?
Yes | No
```